


## Steps for the copying post processor to new PC:

1) On your old PC, you want to go into the folder where you're current post processors are stored.

a. On some versions of VCarve you can simple open a new instance of the software and click "open Application Data Folder...". This will take you straight to the folder you need. Then open "My\_PostP"



b. On older versions of the software, you would need to locate this folder manually using file explorer. The folder is located at: C:\ProgramData\Vectric\VCarve Pro. You then click on the latest version of your software and open "My\_PostP"

2) Copy the post processor(s) that you would like to move over onto a USB stick to transfer to the new computer. You now have all you need from the old PC.

3) Go to the new PC and repeat step 1 to get back to the same folder. Copy the post processor into the My\_PostP folder as it was on the old PC.




4) Make sure all instances of VCarve are closed before opening up a new window. Go to the top menu bar and open Machine > Machine Configuration...

This is where you will create a new 'machine configuration' and assign that new machine a post processor(s).

# Copying post processor to new PC

- Click on the “+” button at the top to add a new machine configuration.
- The first step is to give your machine a name, especially if you have multiple versions of our models. This will be something like Spartan, Falcon or Apollo for example.
- Next, scroll down to the associated post processor section and click on the “+” button again. This will open up a second window displaying all post processor including both VCarve pre-sets as well as your custom imported ones. Helpfully, your custom post processors will be displayed at the top with a pencil icon next to them.
- Click on the post processor you want to assign to this machine and press “select”, then “OK” and you’re done!



Now when you go to save your toolpath, you will see the dropdown where you can select your machine and its associated post processor.

If you have lost your post processor or your old PC is no longer working, the up to date post processors for our current range can be found on the website with this document.

If you cannot see the post processor for your machine, please contact the service department on [service@mantechmachinery.com](mailto:service@mantechmachinery.com) and we can look into sourcing your post processor.

